

ASSEMBLY GUIDE FILM & LG ENVIROPLATE



STEP ONE

Position the plate against the top and left-hand pins.



STEP TWO

Peel back a few centimeters of the adhesive cover at the end of the plate.



STEP THREE

Create a crease in the cover.



STEP FOUR

Align your Clear Film sheet on top, ensuring the printed side is facing downwards.



STEP FIVE

Lightly glide your finger along the edge of the film to ensure it touches the reflective plate.



STEP SIX

Hold the film at the plate's end and slide the plate along the pins towards the roller.



STEP SEVEN

Pass the number plate through the roller while gently pulling away the protective cover.

0115 973 8084





9

£à I

🛞 sales@tennantsuk.com